



FIREFLY PAR

1. Parts



2. Setting up procedure



FIREFLY PAR



Rotate the attached arm on the swivel bracket anticlockwise while pressing the button attached to the ring. Locate the hole in the arm over the stud then release the button so that the stud protrudes through the hole in the arm which will lock it securely into place. See fig. 4, fig. 5 and fig. 6







Insert a tightening bolt into a hole in the center of deflector. See fig. 11 Hold the deflector upside down and screw and an extension rod onto the bolt. See fig. 12 Screw an assembled deflector into the internal pole of Firefly Par. See fig. 13

To keep pace with our continued design and development this product may be modified by Aurora Lite Bank at any time.

123 Secheonro-3-gil, Dasa, Dalsunggun, Daegu 42921, Korea Tel: +82-53-384-9874 Fax: +82-53-384-9886 www.auroralitebank.com e-mail: alb@alb.co.kr © 2017 Aurora Lite Bank. All right reserved